Dlink DSL-2750U

Please follow the below steps to configure Dlink DSL-2750U modem

- Establish a connection between the device and the router via network cable or Wi-Fi (if there's a WIFI password you have to check bottom of the router. If you turn the router over, you should see a sticker, and one of the pieces of information should say something like "Wi-Fi Password" or "WPA passcode.")
- Open a browser and type 192.168.1.1 in the address bar
- You will be prompted to enter Username: admin and Password: admin

Product Page: DSL-2750U   Firmware Version: AF_1.60_R01

D-Link

LOGIN

Welcome to DSL-2750U Web Management

Username : admin ⌄
Password : ●●●●●| admin
☐ Remember my login info.

Login

WIRELESS

- After logging in , Click Setup then Wizard and Setup Wizard

- There are five steps to configure the device. Click Next to continue

- You can click Skip to keep the default password of the router Login

STEP 1: CHANGE DEVICE LOGIN PASSWORD → 2 → 3→ 4 → 5

To help secure your network, D-Link recommends that you should choose a new password. If you do not wish to choose a new password now, just click "Skip" to continue. Click "Next" to proceed to next step.

Current Password :

New Password :

Confirm Password :

Back   Next   Skip   C

- Set time and date if you want then click next.

1 → **STEP 2: SET TIME AND DATE** → 3 → 4 → 5

The Time Configuration option allows you to configure, update, and maintain the correct time on the internal system clock. From this section you can set the time zone that you are in and set the NTP (Network Time Protocol) Server. Daylight Saving can also be configured to automatically adjust the time when needed.

TIME SETTINGS

☐ Automatically synchronize with Internet time servers

First NTP time server : ntp1.dlink.com

Second NTP time server : None

TIME CONFIGURATION

Current Router Time : Thu Jan 1 00:12:43 1970

Time Zone : (GMT-08:00) Pacific Time, Tijuana

Daylight Saving Time rule of US have automatically been applied to this time zone

☐ Enable Daylight Saving,overwrite automatic rule

Month   Week   Day   Time

Daylight Saving Dates :   Start   Jan   1st   Sun   12 am

End   Jan   1st   Sun   12 am

Back   Next   Cancel

- Under Setup Internet connection , Select others as country and Internet Service provider
- Select PPPoE Protocol and LLC as connection type
- Type VPI and VCI , VPI should be 0 if DSP is Ogero and 8 if DSP is GDS while VCI should be 35 then click Next

- Type ADSL Username and Password then click Next

- Make Sure Wireless is enabled and in Wireless Network Name (SSID) type the Name of Wireless
- Select WPA2-PSK as security mode
- In WPA2 Pre-Shared Key type Wi-Fi password then click Next (safest passwords are long and contain at least 8 digits of mixed letters, and numbers)

1 → 2 → 3 → STEP 4: CONFIGURE WIRELESS NETWORK→ 5

Your wireless network is enabled by default. You can simply uncheck it to disable it and click "Next" to skip configuration of wireless network.

☑ **Enable Your Wireless Network**

Your wireless network needs a name so it can be easily recognized by wireless clients. For security purposes, it is highly recommended to change the pre-configured network name.

Wireless Network Name (SSID) : DLINK   (1~32 characters)

Select "Visible" to publish your wireless network and SSID can be found by wireless clients, or select "Invisible" to hide your wireless network so that users need to manually enter SSID in order to connect to your wireless network.

Visibility Status :   ◉ Visible   ○ Invisible

In order to protect your network from hackers and unauthorized users, it is highly recommended you choose one of the following wireless network security settings.

None	Security Level	**Best**

○ None   ○ WEP   ○ WPA-PSK   ◉ WPA2-PSK

Security Mode: WPA2-PSK
Select this option if your wireless adapters support WPA2-PSK.

Now, please enter your wireless security key.

WPA2 Pre-Shared Key : %Fortress123&

(8-63 characters, such as a~z, A~Z, or 0~9, i.e. '**%Fortress123&**')

Note: You will need to enter the same key here into your wireless clients in order to enable proper wireless connection.

Back   Next   Cancel

- When Setup Summary page opens , click Apply to save configuration

Setup complete. Click "Back" to review or modify settings. Click "Apply" to apply current settings.

If your Internet connection does not work after apply, you can try the Setup Wizard again with alternative settings or use Manual Setup instead if you have your Internet connection details as provided by your ISP.

SETUP SUMMARY

Below is a detailed summary of your settings. Please print this page out, or write the information on a piece of paper, so you can configure the correct settings on your wireless client adapters.

Time Settings :	Enable
NTP Server 1 :	igubu.saix.net
NTP Server 2 :	sangoma.saix.net
Time Zone :	(GMT+02:00) Harare, Pretoria
Daylight Saving Time :	Disable
VPI / VCI :	8/35
Protocol :	PPPoE
Connection Type :	LLC
Username :	abc001-cn1@dsl-uc.isat.co.za
Password :	000000
Wireless Network :	Enabled
Wireless Network Name (SSID) :	DLINK
Visibility Status :	Visible
Encryption :	WPA2-PSK/AES (also known as WPA2 Personal)
Pre-Shared Key :	%Fortress123&

Back Apply Cancel